



# SMOKED FOG LIGHT COVERS

(2018-2023+ WRANGLER SPORT)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (2) Fog Light Covers
- (2) Alcohol Prep Pads
- (2) Adhesion Promoter Pads

### TOOLS REQUIRED

---

N/A



## STEP 1

Locate the vehicle fog light.

Clean the fog light lens using the included (1) alcohol prep pad, and allow to dry.

Then, clean the fog light lens using the include (1 ) adhesion promoter prep pad, and allow to dry.



## STEP 2

Test fit the fog light cover before removing the tape backing to familiarize fitment. Once familiar, peel the red tape backing from the cover, and firmly press the cover onto the fog light lens. Apply firm even pressure to ensure proper adhesion.

Repeat steps 1-2 for the remaining fog light cover. Installation is now complete.