



SMOKED FOG LIGHT COVERS

(2018-2024+ WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (2) Reflector Covers
- (2) Alcohol Prep Pads
- (2) Adhesion Promoter Pads

TOOLS REQUIRED

N/A



STEP 1

Locate the vehicle rear bumper reflector.

Clean the reflector using the included (1) alcohol prep pad, and allow to dry.

Then, clean the reflector using the include (1) adhesion promoter prep pad, and allow to dry.



STEP 2

Test fit the reflector cover before removing the tape backing to familiarize fitment. Once familiar, peel the red tape backing from the cover, and firmly press the cover onto the bumper reflector. Apply firm even pressure to ensure proper adhesion.

Repeat steps 1-2 for the remaining reflector cover. Installation is now complete.