



# HD GRAB HANDLES

(2018-2024+ WRANGLER JL - 2 DOOR)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(2) Grab Handles  
(4) M10x1.50 x 65mm Bolts [Front]  
(4) M10 Flat Washers  
(4) M10 Nuts  
(1) 8mm Allen Key  
(2) Foam Gaskets

### TOOLS REQUIRED

---

8mm Allen Key

## STEP 1 [FRONT]



Locate the (2) through holes in the vehicle roll bar.

## STEP 2 [FRONT]



Place the foam side of the grab handle onto the top of the vehicle roll bar. Then, place (2) M10 nuts into the grab handle hex cutouts. Through the bottom of the roll bar, insert (2) M10 x 65mm bolts through the roll bar and into the previously placed M10 nuts. Tighten the bolts evenly until the grab handle is secure.

Installation is now complete.