

LED THIRD BRAKE LIGHT

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Third Brake Light

TOOLS REQUIRED

T-20 Torx Screwdriver
Small Pry Tool

STEP 1



Remove (2) T-20 Torx screws from the third brake light assembly. Then, use a small pry tool around the perimeter to dislodge the light assembly from the tire carrier light housing.

STEP 2



Remove the original light bulb and socket from the tail light assembly. Then, plug the new light wiring connector into the original light bulb socket. Turn the socket into place to the tail light.

Note: It is recommended to test the light at this stage. Some LED lights are polarized. If the light does not work, remove the socket and turn the wiring harness connector 180 degrees, and re-install.



STEP 3

Plug the tail light into the vehicle harness, and secure the assembly to the tire carrier light housing using the original (2) T-20 Torx screws.

Installation is now complete.