

LED SEQUENTIAL CORNERING LIGHTS

(1997-2006 WRANGLER TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Cornering Light
(1) RH Cornering Light

TOOLS REQUIRED

T-15 Torx Screwdriver/Bit



STEP 1

Remove (2) T-15 Torx screws securing the OEM corner light to the vehicle.



STEP 2

Remove the corner light from the vehicle, and turn the light socket counter-clockwise to release the socket from the housing. Remove the OEM light bulb from the socket.

Identify the new lights fitment location utilizing the dowel locations on the new light compared to the dowel openings in the fender.



STEP 3

Fit the lightbulb-style connector into the vehicle light socket.

Turn on the vehicle lighting to confirm functionality. The lights are polarized; If the lights do not power on, unplug the connector and turn the light connector 180° and re-test lighting.

Adhere the resistor to the inside of the fender using the pre-installed adhesive pad.



STEP 4

Install the new light into the vehicle using the original (2) T-15 Torx screws.

Repeat steps 1-4 for the remaining corner light.

Installation is now complete.