

OE-REPLACEMENT SOFT TOP

(1997-2006 WRANGLER TJ - EXCLUDING UNLIMITED)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Soft Top
- (2) Side Windows
- (1) Rear Window

TOOLS REQUIRED

Phillips Head Screw Driver Flat Head Screw Driver Pliers





Remove factory quarter and rear windows, uninstall the tailgate bar attached to the bottom of the rear window from the plastic clamps. Next, unlatch the plastic tabs holding the top to the door channels by pulling down and away from your Jeep and unhook the windshield latches, freeing the top from the windshield.



STEP 2

Unhook the back corners of the top by pulling down and away from the vehicle to free the plastic strip from the channel.





Unhook the factory top from the rear bow by unsnapping it. Next, unhook the center bow flap to completely separate the top from the frame.



STEP 4

Finally, remove the screws holding the top to the header panel, put them aside, and remove the top fabric from the vehicle.





With both the center and rear bows laying down on the rear of the vehicle, lay the fabric over the top with the backing side up. Line the plastic strip up with the edge of the header and using the center hole, screw the fabric down. After the center is secure, you can then proceed to secure the rest of the plastic strip.



Raise the top toward the windshield and lock it into place. Then, snap the fabric onto the rear bow.





Pull down the rear corners of the top, and secure the corners to the vehicle, then close the header latches. *Depending on how tight your top is, it may help to release the windshield latches, and or let the top sit outside in the sun.



STEP 8

Fasten the center bow to the fabric top by velcroing it in place.





Install the quarter windows by zipping them into place. Then secure the plastic strips into the channels on the body and door surround.



STEP 10

Slide the plastic strips along the top into the door surround channels above the passenger and driver doors.





Install the tailgate bar onto the rear window and insert the assembly into the mounts with the vinyl side out. Zip up the window and cover the zipper ends with the overlapping fabric from the rear corners attached in Step 8.

Installation is now complete.