



DOOR MOUNT FOR 6L JERRY CAN

(2007-2018 WRANGLER JK)
(2018-2024+ WRANGLER JL)
(2020-2024+ GLADIATOR JT)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Door Bracket w/ Rubber Bumpers
(1) Jerry Can Mount Spacer
(4) M8x1.25 x 35mm Allen Bolts
(4) M8 Flat Washers
(4) M8 Conical Spacers
(4) M6x1.00 x 30mm Allen Bolts
(8) M6 Flat Washers
(4) M6 Lock Nuts

TOOLS REQUIRED

T-50 Torx Socket
5mm Allen Socket
10mm Wrench
Ratchet

SKU # J236531



STEP 1

Fit the jerry can mount with the included spacer to the mounting bracket, and secure into place using (4) M6 x 30mm Allen bolts, (8) M6 flat washers, and (2) M6 lock nuts. Tighten until secure.



STEP 2

Ensure the vehicle door is fully closed. Then, remove (1) T-50 Torx bolt from top door hinge. Fit the bracket to the bolt hole, ensuring there is (1) conical spacer between the bracket and the vehicle hinge. Secure the bracket to the hinge using (1) M8 x 30mm Allen bolt and (1) M8 flat washer. Remove the remaining (3) T-50 Torx bolts from the vehicle hinges.

*Fitting the bracket secure with (1) Allen bolt is required to keep the vehicle door alignment true while removing the remaining (3) Torx bolts.

STEP 3



Hinge the bracket over the vehicle hinge bolt holes, and fit the (3) conical spacers into the vehicle hinges. Secure the bracket using (3) M8 x 30mm Allen bolts and (3) M8 flat washers. Tighten all (4) M8 bolts until the bracket is fully secure.

STEP 4



Fit the jerry can to the mount, and tighten the mount to secure the jerry can into place.

Installation is now complete.