



JK Ultimate Rubicon Front Sway Links Instructions

1. With Jeep on level ground remove old links and hardware.
2. Install so the aluminum spacer goes between the heim and the mounting bracket.
3. On the passenger side lower, you may need to notch the spring pad.

Suggested lengths:

2.5" Lift 11"

3.5" Lift 12"

4.5" Lift 13"

5.5" Lift 14"

Warranty:

Center aluminum section is lifetime warrantied for failure, including bending, cracking, or breaking. Should any of these failures occur please send the center section to RPMSTEERING for replacement. (Shipping and handling additional).

Disclaimer:

Customer assumes full responsibility for use, installation and routine maintenance. RPM Steering is not responsible for damage as a result of improper installation, use or maintenance.

