

## 2015 - 2018

### JEEP Wrangler Unlimited

**TRIM LINE INSTRUCTIONS:** Floor Mat trim patterns vary per vehicle make and model.

\* Please ensure you are 100% satisfied with your purchase before \*  
trimming, as this will void your return and warranty

#### STEP 1:

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.



**Mat Shown Trimmed For Vehicles With Optional Subwoofer**



#### STEP 2:

Trim using sharp scissors or a carpenter's knife to cut along crevice in mat to remove area as shown to equipped with optional under seat subwoofer.



smartlinerusa



Smartliner-USA



Smartliner USA