



21” TRAIL ANTENNA

(2007+ WRANGLER)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) 21” Trail Antenna

TOOLS REQUIRED

Adjustable Wrench

STEP 1



Using an adjustable wrench, loosen the antenna from the base and remove it from the vehicle.

STEP 2



Install the new antenna by twisting it clockwise.