



SHORT ANTENNA

(UNIVERSAL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Antenna
- (5) Threaded Adapters
- (2) Plastic Adapters

TOOLS REQUIRED

Small Adjustable Wrench

STEP 1



Using a small adjustable wrench, rotate the antenna counter-clock wise to remove it from the vehicle.

STEP 2



Compare the included threaded adapters to the OEM antenna to find the appropriate adapter. Once the appropriate adapter is found, thread the adapter onto the new antenna until secure.

Test fit the antenna to the vehicle. If necessary, use the included plastic spacers to provide the best fit/finish. Once the appropriate adapters/spacers are fitted, fit the antenna to the vehicle and turn clockwise until secure. Installation is now complete.