




Installation Instructions

PARTS LIST:

Qty	Item Description	Qty	Item Description
1	Push Bar	1	5mm Wrench
1	Driver/left Side Tube	2	8-1.25mm x 30mm Hex Combo Bolts
1	Passenger/Right Side Tube	4	8-1.25mm x 25mm Button Head Bolts
1	Driver/left Offset Shackle Mount	6	8mm x 22mm x 2mm Flat Washers
1	Passenger/Right Offset Shackle Mount	4	8mm x 16mm x 1.6mm Flat Washers
1	Driver/left LED "L" Bracket	2	8-1.25mm x 25mm Hex Bolt
1	Passenger/Right LED "L" Bracket	2	8-1.25mm x 16mm Hex Bolt
1	License Plate Bracket	8	8mm Lock Washers
2	Plastic Plugs for License Plate	6	8mm Hex Nuts
4	Plastic Hole Plugs	2	6-1.0mm x 20mm Combo Bolts
1	4mm Wrench		



TOOLS REQUIRED






13 & 19mm Socket







Extensions

Follow (Fig 1-4) to remove standard U-Covers, Shackle Mounts, and other hardware to prepare for Push Bar Installation.









(Fig 2) Remove hardware attaching Shackle Mount to bumper





Page 2 of 4 7-1-24 (JY) 2


Follow (Fig 5-12) to attach Offset Shackle Mounts, then install Push Bar and connect Push Bar Wings. Then reinstall U-covers. Ensure fasteners are hand tight at this point.














Page 3 of 4 7-1-24 (JY)






3



Ensure Push Bar is level and properly fit, then tighten all fasteners. Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.



Page 4 of 4