



INSTALLATION INSTRUCTIONS

Ultra Block Thermal Acoustic Lining

KIT CONTENTS:

#50511 Ultra Block - 48" x 48" sheet

SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of DEI products.

TOOLS:

Scissors or snips, Cardboard/Poster board to use as a template

**INSTALLATION QUESTIONS? CONTACT DEI AT 800-264-9472
OR VIA EMAIL AT TECH@DESIGNENGINEERING.COM**

INSTRUCTIONS:

1. Making a template will aid in proper and professional installation.
2. Using cardboard or poster board trace an outline of the area to be covered. Cut out template and transfer to Ultra Block.
3. Trim Ultra Block to desired size using a sharp scissors or snips.
4. Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of products.
5. Remove the backing to expose the adhesive and carefully apply to clean and dry desired area.
6. After Ultra Block is set in proper location, apply pressure to ensure a strong bond with installation surface.

