


INSTALLATION INSTRUCTIONS

UNIVERSAL RUNNING BOARD

Parts List				
Item	Qty.	Code	Description	Max. Torque
1	1 Set	-	Running Board	-
2	6 Pc.	396804AA	U (Clamp) Bracket *	-

* Wheel to Wheel Running Boards have the U (Clamp) Brackets included on the Bracket Kit (Sold Separately)


Required Tools (Not included)	
Qty.	Description
1	15mm Wrench
1	17mm Socket
1	Ratchet



Instructions

- Before beginning the installation, please read all directions carefully and verify that all necessary hardware is accounted for. If any parts are missing, stop the installation and contact your distributor immediately.
- To maintain and care this product keep it clean and do not use abrasive cleaners or polish waxes. We recommend to use only non-abrasive automotive wax such as pure carnauba to avoid scratches and rust.
- Once the main brackets are installed (**sold separately**), the approximate installation time is **15 min.**
- Place the U brackets inside the Running Board. Move them to align to the main brackets. **See illustration 1.**
- Place the flat and lock washers with the square head bolts. This hardware kit is included on the main brackets that are (**sold separately**). **See illustration 1.**
- Align the Running board and tighten the bolts using a 1/2" wrench.
- NOTE: For some regular cabs only two U brackets are needed per side.**

ILLUSTRATION 1.





INSTALLATION INSTRUCTIONS

PART NO.


- 6842395

PRODUCT DESCRIPTION:

- OE Xtreme Brackets

VEHICLE APPLICATION

- Dodge Durango
- Jeep Grand Cherokee



PRODUCT SAFETY & LEGAL DISCLAIMER

- **IMPORTANT READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING, FAILURE TO DO SO MAY CAUSE PERSONAL INJURY OR DAMAGE TO PRODUCT AND/OR PROPERTY.**
- **Review the product package and contents prior to beginning the installation.** Take care when opening the packaging and removing items. If a return is needed you will want to return the product in its original packaging if possible.
- This instruction guide is provided as a GENERAL installation guide, some vehicles vary dimensionally and may require additional steps.
- Test fit the product on the vehicle prior to any third party modifications and or finishing. The manufacturer and/or distributors do not accept responsibility for third party charges, labor and or third part replacement modifications. Some modifications may void the factory warranty.
- Exercise due-diligence when installing this product. The manufacturer and distributors of this product do not accept any responsibility for vehicle damage or personal injury resulting from the installation of this product. Careless installation and operation can result in serious injury or equipment damage.
- This product is for general off-road use. All liability for installation and use rests with the owner/operator.
- **INSTALLER:** Once installation is complete, please return this guide along with other documentation included in this product back to the consumer for future reference. The manufacturer/distributors of this product do not guarantee this particular version will be available at a later date.

© 2016 Go Rhino Products. All rights reserved

www.gorhino.com

589 W. Apollo St., Brea, CA 92821

P: 888 427 4466



INSTALLATION INSTRUCTIONS

INJURY HAZARD

Please complete a shop and tool inspection prior to beginning the installation.

- Always make sure you have a clean, dry and well lit work area.
- Always remove jewelry, loose fitting clothing and wear protective gloves and eye protection.
- Always use extreme caution when jacking or raising a vehicle for work. Set the emergency brake and use tire/wheel blocks and jack stands. Refer to the vehicle manufacturer hand book. Utilize the vehicle manufacturers designated lifting points.
- Always use appropriate and adequate care in lifting parts during disassembly and installation. Seek help in lifting heavy or large items into place. Utilize jacks and or lifting devices when available.
- Always insure products are secure during disassembly and installation.
- Always wear eye protection and take steps to protect any exposed skin during the installations. Drilling, cutting and grinding plastic and metal may create flying particles that can cause injury.
- Always use extreme caution when drilling, cutting and or grinding on a vehicle. Thoroughly inspect the area to be drilled, on both sides of material, prior to modification and relocate any objects that may become damaged.
- Always assemble and tighten all fasteners per the installation instructions.
- Always route electrical cables carefully. Avoid moving parts, parts that may become hot and rough or sharp edges.
- Always insulate and protect all exposed wiring and electrical connections.

MAINTENANCE AND CARE

- Always perform regular inspections and maintenance on mounts and related fasteners.
- Periodically check and tighten all fasteners.
- Stripped, fractured, or bent fasteners must be replaced.
- After washing the vehicle make sure to fully dry all surfaces.
- In areas with cold temperatures make sure to wash the product often to remove harmful materials used on road ways.
- Never use abrasive cleaners or polish compounds. Clean with a gentle soap and water. If you use wax use a non-abrasive automotive wax such as pure carnauba wax.

WARNING


Some products have been designed to work together with factory rear sensor systems, factory forward facing sensor systems and factory air bags.

- Installation of some of these products may alter the factory sensor system performance.
- Factory sensors may read shackles or hooks protruding from the fairlead and or tow hooks.
- All sensor testing is completed by Go Rhino Products and or third party testing labs on modified vehicles.
- Sensor sensitivity, factory sensor housing, orientation, and operating conditions are all variables that will influence functionality of the sensors.
- Installation of some product may effect the factory air bag systems.
- Some products allow the use of third party products such as winches, shackles, hooks, etc. Follow the respective manufacturers operating instructions for use with our products.
- Make sure to fully understand the product, it's intended use and operation prior to use.
- Above all... be safe!



INSTALLATION INSTRUCTIONS

PARTS INCLUDED IN THIS LIST:



Item	Qty.	Description	Max. Torque
1	2 Piece	Front bracket (Taller Bracket)	-
2	2 Piece	Rear bracket (Shorter Bracket)	-
3	2 Piece	Auxiliary front bracket.	-
4	2 Piece	Auxiliary rear bracket.	-
5	4 Piece	3/8" Bolt plate.	30 Lb.ft
6	2 Piece	5/16" Bolt plate.	20 Lb.ft
7	8 Piece	5/16" Square head bolt. Zinc black	-
8	8 Piece	5/16" Flat washer. Zinc black	-
9	8 Piece	5/16" Lock washer. Zinc black	20 Lb.ft
10	2 Piece	5/16" Flat washer. Zinc plate	-
11	2 Piece	5/16" Lock washer. Zinc plate	-
12	2 Piece	5/16" Hex nut. Zinc plate	20 Lb.ft
13	4 Piece	3/8 x 1 1/4" Carriage head bolt. Zinc black	30 Lb.ft
14	4 Piece	3/8" Flat washer. Zinc black	-
15	4 Piece	3/8" Lock washer. Zinc black	-
16	4 Piece	3/8" Hex nut. Zinc black	30 Lb.ft
17	4 Piece	3/8" Flat washer. Zinc plate	-
18	4 Piece	3/8" Lock washer. Zinc plate	-
19	4 Piece	3/8" Hex nut. Zinc plate	30 Lb.ft

Go Rhino recommends you, the installer, read this installation instruction manual from front to back before installing the product. You may also [click here](#) to view an installation video or visit <http://www.gorhino.com/Installation-Videos>.

TOOLS NEEDED FOR INSTALLATION:

- 9/16" Socket & Wrench
- 13mm Socket & Wrench
- 1/2" Socket & Wrench

ESTIMATED TIME FOR INSTALLATION:




1 hr

If you need installation service for your new product, call the authorized distributor from whom you purchased the product or an authorized installation service company which can be found by calling toll free 1-888-427-4466

GO RHINO®

INSTALLATION INSTRUCTIONS

Driver Side Orientation



Step 1: Prepare the Mounting Area

- Locate the plastic caps on the holes in the rocker panel.
- Use a flat-head screwdriver to remove these caps.
- Refer to **Pictures 1 and 2** to identify the exact hole locations.

Step 2: Install the Front Bracket


- Insert a **3/8" bolt plate** into the front hole, ensuring the plate surface is inside and outside the bolt body (see **Pictures 1 and 2**).
- Position the **front bracket** over the bolt.
- Secure it using the following hardware (in this order):
 - 3/8" flat washer (zinc-plated)
 - 3/8" lock washer (zinc-plated)
 - 3/8" hex nut (zinc-plated)
- **Leave the hardware loose** for now.
- Refer to **Illustration 1** for visual guidance.

Note: Repeat this step to install the **rear bracket** using the same method.




INSTALLATION INSTRUCTIONS

PICTURE 4.



PICTURE 5.



Step 3: Install the Front Auxiliary Bracket

- Locate the chassis hole behind the front bracket (see Pictures 4 and 5).
- Insert a **5/16" bolt plate** into this hole.
- Place the **front auxiliary bracket** over the bolt.
- Secure with:
 - 5/16" flat washer (zinc-plated)
 - 5/16" lock washer (zinc-plated)
 - 5/16" hex nut (zinc-plated)
- **Leave loose.**



Step 4: Connect Auxiliary Bracket to Front Bracket

- On the opposite side of the front auxiliary bracket, align it with the front bracket.
- Use the following hardware to connect them:
 - **3/8" x 1 1/4" carriage head bolt** (zinc black)
 - 3/8" flat washer (zinc black)
 - 3/8" lock washer (zinc black)
 - 3/8" hex nut (zinc black)
- **Leave the assembly loose.**
- Refer to **Illustration 2** for details.



INSTALLATION INSTRUCTIONS

PICTURES A, B, C.



Step 5: Install the Rear Auxiliary Bracket

- Locate the **OEM bolt** behind the rear bracket on the vehicle.
- Loosen the bolt just enough to insert the **rear auxiliary bracket** (see Pictures A, B, C).
- Do not fully tighten yet.
- Attach the rear auxiliary bracket to the rear bracket using:
 - **3/8" x 1 1/4" carriage head bolt** (zinc black)
 - 3/8" flat washer (zinc black)
 - 3/8" lock washer (zinc black)
 - 3/8" hex nut (zinc black)
- **Leave loose.**
- Refer to **Illustration 3**.

Step 6: Final Adjustments

- Align all brackets to ensure proper fit and orientation.
- Fully tighten all bolts and hardware.

Step 7: Repeat for Passenger Side

- Follow the same steps above to install brackets on the passenger side.

Step 8: Maintenance

- Periodically inspect the installation.
- Re-tighten bolts as necessary to ensure safety and stability.



INSTALLATION INSTRUCTIONS

LIMITED WARRANTY

Go Rhino warrants to Buyer that for a period of five (5) years from the date of shipment of the product(s) ("Warranty Period") for black finishes and chrome finishes, that such products will materially conform to the specifications set forth in Go Rhino's specifications in effect as of the date of shipment(s) and will be free from material defects in material workmanship.

Go Rhino warrants to Buyer that for the life of the product(s) from the date of shipment of the product(s) ("Warranty Period") for polished stainless steel finished products purchased after April 2004, that such products will materially conform to the specifications set forth in Go Rhino's specifications in effect as of the date of shipments and will be free from material defects in material workmanship.

Warranty claims must be accompanied with the original invoice and photos of the product. It is the customer's responsibility to clean regularly and protect finish with regular applications of a nonabrasive polish that is compatible with the product's finish.

This warranty covers the cost of the product only and does not include the cost of removal, installation, third party modifications or shipping of the product. In no event shall Go Rhino be liable to buyer or any third party for any damage or harm caused by the product or use thereof, regardless of weather such damages were foreseeable and whether or not Go Rhino has been advised of the possibility of such damages, not withstanding the failure of any agreed or other remedy of its essential purpose. This warranty is void if the product shows signs of alteration, misuse, mishandling, improper care, neglect, improper application and/or damage due to improper installation.

With respect to any such product(s) during the limited warranty period, Go Rhino shall, in its sole discretion, either: (i) provide a one-time repair or replacement of such products (or the defective part) or (ii) credit or refund the price of such products at the pro rata contract rate provided that, if Go Rhino so requests, Buyer shall, at Go Rhino's expense, return such product(s) to Go Rhino. The remedies shall be the Buyer's sole and exclusive remedy and Go Rhino's entire liability for any breach of the limited warrant(ies).

Go Rhino disclaims all other warranties except to the extent that any such warranty cannot be validly disclaimed under applicable law.

Finish Limited Warranty:

Limited lifetime on stainless steel products (after April 2004)

5 year warranty on black powder coat products

5 year warranty on chrome products

This warranty does not cover exposed welds

Finish warranty covers peeling, flaking, or cracking. Washing all finishes regularly with car wash soap and rinsing well with water is the best method for maintaining the finish on your products. You must also protect the finish with nonabrasive automotive wax on a regular basis. The use of any compound which contains abrasives becomes a self-defeating exercise as the compound scratches the finish and opens it to corrosion. The use of harsh chemicals used to remove bugs and tar may also cause the finish to fail and should be avoided.

If you are unsatisfied with your purchase please contact the establishment you purchased the product from.

If you need to place a warranty claim or need assistance, the Go Rhino customer service team will answer any questions you may have. Please contact the Go Rhino customer service team at 1-888-427-4466 during normal business hours Monday thru Friday 7 am to 5 pm PST. You may also email warranty@gorhino.com. In order to better serve you please provide a copy of the original invoice / receipt, a photo of the issue you are experiencing and a photo of the vehicle the product is installed on.

All warranty returns must have an approved RGA number. The RGA number must be clearly marked on the exterior of the return package. All approved warranty returns must be shipped to Go Rhino Products, 1002 Carriers Drive, Laredo, Texas 78045.

PRODUCT REGISTRATION

Please remember to register your new purchase. You may register your product at www.gorhino.com. Registering your product may help speed any future warranty or customer service inquiries.

Thank you again for purchasing from Go Rhino Products

Please take a few minutes to view additional products for your vehicle and more at GORHINO.com
These installation instructions are available on the Go Rhino web site along with installation videos for many of our products.

www.gorhino.com

www.bigcountryauto.com

www.gorhinopd.com