



Thank you for your business

1. All of our compression fit consoles are designed to remove from the box and slip over your console.
2. We suggest using the velcro backing that is installed on the back of your console.
3. Clean your vehicle's console with windex first or a light soapy water mixture.
4. Then clean with 98% alcohol to remove any soap or waxy coating.
5. Test fit to the vehicle's console to see where the velcro backing will sit to make sure you have cleaned enough off.
6. Remove the backing from the underside of the metal console.7. Press firmly into place on the vehicle's console.8. Not all legs or rubber legs will touch the vehicle's console. The metal Molle PSD Console is made to take a load. Make sure to load the rubber feet to the touch console.

If you have any questions contact us.

sales@orangeboxxfab.com

Our hours are Monday - Friday 9am - 4:30 pm eastern

Tag us on Instagram

#orangeboxxfab