



**Thank you for your business**

Tools needed for installation

Phillips head screwdriver

10mm socket ratchet combination

10mm wrench open end and box end

5mm Allen wrench

Thank you for purchasing a Gen 4 4Runner side PSD.

1. Remove the upper coat hook. If dual hook the closest one to the rear.
- 2 .Remove cap from forward position in luggage area. This will expose the threaded area for attachment. Remove rear cover,screw at luggage cover bracket.
3. Attach the bent bracket to the top of the PSD (Molle rack) to the correct side (PSD Driver or Passenger side) with bent part facing towards you using 2 Bolts and nuts provided in kit.  
Leave loose. The bracket belongs to the rear of the rack.
4. Attach the bent bracket under the coat hook. Leave loose for

adjustments. The bracket bottom

should be facing towards glass. Screw in the bolt to hold on the upper hook and leave all loose.

5. Place the 4.250" spacer in the front hole closest to the front of the 4runner using a 4.625" 6mm bolt. Use the 3.00" spacer at the rear of the 4runner with 4.00" 6mm bolt.

6. Adjust twist side to side so that the top of the rack is even by eye to the top of the window looking out. Tighten upper bracket at .500" 6mm at bracket. Tighten upper support at coat hook. Tighten front and rear bolts.

7. Tighten all bolts and nuts.

If you have any questions contact us. [sales@orangeboxxfab.com](mailto:sales@orangeboxxfab.com)

Our hours are Monday - Friday 9am - 5pm eastern

Call us (336)804-0571