



Thank you for your business

Tools needed to install Screw in.

3/64 Drill bit (NEW)

Drill

Phillips head screwdriver

Small C-clamp

!! This is a 2 Person job. !!

DO NOT GET IN A HURRY

Please read instructions in full before starting.

1. In your kit you will receive

A. Rear window PSD.

B. Self tapping screws.

C. Rubber edge guard already installed on rear window hatch.

2. Place the rear window molle panel up to the window opening with the rear glass window

down. Find the center of your window opening. Center the rack in the window opening from side to side. Make sure the bottom of the rack is pressed against the plastic on the bottom of the window opening. Place a

small C-Clamp in the window opening pinching the rack and the sides of the window to check the rack with the opening.

3. Using the 3/64 drill bit start in the center top drill the first hole and install screw. Work your

way evenly across the top and then down the sides. Do not allow the rack to buckle at the bottom.

If you do not have the removable center you may stop here

4. If this is a removal rear hatch do not remove the center section while installing. The center section keeps the whole unit from bending while installing. After the screws are installed you can then remove the center section. To store the center section when not in use it is designed to fit on the self (attic) unit if you have one from us.

All removable center sections can be reordered to interchange with each other.

This is a 2 person job.

If you have any questions contact us. sales@orangeboxxfab.com

Our hours are Monday - Friday 9am - 5pm eastern

Call us (336)804-0571