



Thank you for your business

carabiner hook install instructions.

Tools needed for installation

- Small flathead screwdriver
- Medium phillips head screwdriver
- 10mm Socket ratchet socket combination

Please read all instructions before starting installation.

1. With a small flat head screwdriver pry open cover over coat hook from small indention on seem.
2. With the 10mm socket remove the bolt inside.
3. Remove the upper coat hook.
4. Place carabiner hook under the coat hook through the metal hole in the hook.
5. Replace the coat hook with the carabiner hook facing towards the interior of the vehicle.
6. Replace the bolt and tighten. Make sure to keep the assembly straight.
7. Push cap back into place.

If you have any questions contact us.

sales@orangeboxxfab.com

Our hours are Monday - Friday 9am - 4:30 pm eastern

Call us (336)804-0571

Tag us on Instagram

#orangeboxxfab