



STAINLESS STEEL EXHAUST TIP

(2018-2023 4RUNNER)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Exhaust Tip
(1) Exhaust Clamp

TOOLS REQUIRED

8mm Socket
Ratchet

STEP 1



Fit the clamp inside of the cutouts in the bottom of the exhaust clamp, position the clamp as shown. Then, slide the clamp upwards into the exhaust tip. Ensure the clamp is loose enough to fit over the vehicle exhaust pipe.

STEP 2



Fit the exhaust tip over the vehicle exhaust pipe. Tighten the exhaust clamp to secure the tip to the vehicle exhaust pipe. Tighten until the exhaust tip is secure.

Installation is now complete.