



# PREDATOR SIDE STEPS

(2005-2023 TACOMA DOUBLE CAB)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) Driver Side Step
- (1) Passenger Side Step
- (10) M8x1.25 x 25mm Bolts
- (10) M8 Flat Washers

### TOOLS REQUIRED

---

- 13mm Socket
- Socket Wrench

SKU # TT11503

**STEP 1**

With assistance, align the side step to the pre-drilled holes under the vehicle. Use the provided (5) M8x1.25 x 25mm bolts and (5) M8 flat washers to secure the side step to the vehicle. Tighten until secure.

**STEP 2**

Repeat step 1 to the opposite side.

Installation is now complete.