



# FRONT BUMPER 30" LED LIGHT BAR MOUNT

(2005-2015 TACOMA)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Light Bar Bracket
- (1) RH Light Bar Bracket
- (2) M8 Bolts

### TOOLS REQUIRED

---

- 14mm Wrench
- Rotary Tool

SKU # TT13257



**STEP 1**

Remove (2) 14mm nuts from the outside of the vehicle crash bar. Repeat this procedure for the opposite side of the vehicle.



**STEP 2**

Align the light bar mount to the crash bar mounting studs. Once aligned, secure the light bar mount using the (2) original 14mm nuts.

Note: Trimming may be required at this step to fit the light bar mount.



---

**STEP 3**

Using a rotary tool, trim the inner grille within both of the light bar mounts. Mount light bar into the light bar mounts.

Installation is now complete.