



MUD GUARDS

(2016-2023 TACOMA WITH OE FENDER FLARE)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Pair of Front Mud Guards
- (1) Pair of Rear Mud Guards
- (4) Phillips Screws

TOOLS REQUIRED

- 10mm Socket
- Ratchet
- Phillips Screwdriver
- Spray Detailer
- Microfiber Cloth

SKU # TT13258



**STEP 1
(FRONT)**

Remove the original (3) 10mm bolts from the fender.

Note: (1) 10mm bolt is along the bottom of the fender.



STEP 2

Clean the bottom of the fender to prevent trapping any dirt and debris inside the mud guard. Align the fender into place. Re-install the (3) 10mm bolts into the original location.

**STEP 3**

Use (1) provided Phillips screw to secure the inside of the mud guard to the pre-installed plastic insert in the vehicle. Tighten until secure.

Repeat steps 1-4 to the opposite side.

**STEP 4
(REAR)**

Remove the (4) 10mm bolts from the fender.

Note: (1) 10mm bolt is along the bottom of the fender.

**STEP 5**

Clean the bottom of the fender to prevent trapping any dirt and debris inside the mud guard. Align the fender into place. Re-install the (4) 10mm bolts into the original location.

**STEP 6**

Use (1) provided Phillips screw to secure the inside of the mud guard to the pre-installed plastic insert in the vehicle. Tighten until secure.

Installation is now complete.