



UNDER SEAT LOCK BOX

(2005-2015 TACOMA DOUBLE CAB)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Lock Box
- (1) LH Mounting Bracket
- (1) RH Mounting Bracket
- (2) Keys
- (2) M6x1.00 x 25mm Allen Bolts
- (4) M6x1.00 x 12mm Allen Bolts
- (2) M6 Flat Washers

TOOLS REQUIRED

- 10mm Socket
- Ratchet
- 4mm Allen Key/Socket

**STEP 1**

Assemble the storage box by installing the (2) brackets to the back side of the lock box using (2) M6 x 12mm Allen bolts per bracket.

Note: Do not fully tighten the Allen bolts to allow adjustability later.

**STEP 2**

Fold the driver side rear seat down to reveal the storage area behind the back rest. Remove (2) 10mm bolts from the storage area.

**STEP 3**

Align the lock box to the storage area of the vehicle. Fold the lid down, then secure the lock box to the vehicle using the (2) M6 x 25mm Allen bolts and (2) M6 flat washers.

Note: Ensure the top edge of the lock box is flush to the storage area for the best fit.

**STEP 4**

Tighten all hardware to secure the lock box into place.

Installation is now complete.