



HEADREST MOLLE PANEL SET

(2005-2021 TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Headrest Molle Panels

TOOLS REQUIRED

N/A

STEP 1

Raise the seat headrest using the buttons between the seat and the headrest. Insert the molle panel cutouts into the headrest mounting posts to secure the molle panel to the vehicle headrest.

STEP 2

Adjust the headrest to achieve the desired height. Repeat steps 1-2 to the opposite side of the vehicle.

Installation is now complete.