



BLACK HORSE OFF ROAD®

Installation Instructions

Workhorse Auto Safe

Part# ASTT06 Fits: - TOYOTA TACOMA 2016 – 2023

Tools Needed:
1xSocket Wrench





Safe installation

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Use a socket wrench to remove the **2 BOLTS** at the bottom of the armrest box.

STEP 3 Remove the padding from the bottom of the inside of the safe.

STEP 4 Insert the safe into the armrest box.

a. Keep the safe door open to ensure the safe is inserted into the armrest box correctly, make sure that the 2 holes at the bottom of the safe line up with the factory holes in the armrest box.

STEP 5 Use a socket wrench to tighten the bolts, **DO NOT over-tighten bolts, over-tightening will damage the armrest safe.**

STEP 6 Replace the padding in the floor of the safe.

Setting the Combination

The factory preset combination is 0-0-0-0

Please keep the safe door open when changing the combination.

To change the combination, insert the coding pin provided into the hole in the side of the lock.



Remove the coding pin to lock in the combination. Test the lock operation before closing the safe door.

Please note: The combination can only be changed again by setting the saved combination and inserting the pin. Please record the combination on the card provided.