



WIRELESS CHARGING STATION

(2016-2023 TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Wireless Charging Station
Storage Tray
- (1) USB-C Cable
- (1) 12V Outlet Connector

TOOLS REQUIRED

N/A



STEP 1

Clean contents from the center console to allow fitment of the wireless charging station tray.

Locate the 12V Outlet in the center console.



STEP 2

Plug the USB-C Cable into the wireless charging station tray, ensure the cable is fully inserted. Then, plug the USB cable into the vehicle power port, use the included 12V outlet connector if necessary.



STEP 3

Fit the wireless charging station tray into the grooves along the front and back of the center console. Once fitted, with the vehicle powered on, press the power button and test functionality. Fit the included liners into the tray.

Installation is now complete.