
INSTALLATION INSTRUCTIONS

PARTS LIST:

Qty	Item Description	Qty	Item Description
1	Driver/Left Side Bar	2	Passenger/Right Center/rear Mounting Brackets
1	Passenger/right Side Bar	12	8mm Lock Washers
1	Driver/Left Front Mounting Bracket	12	8mm x 24mm OD x 2mm Flat Washers
2	Driver/Left Center/rear Mounting Brackets	12	8-1.25mm x 30mm Hex Bolts
1	Passenger/Right Front Mounting Bracket	12	8-1.25mm x 25mm Combo Bolts



4" Oval Bent End Sidebar 24+ Toyota Tacoma Double Cab

TOOLS REQUIRED






13mm Socket







1

Follow (Fig 1 - 9) to attach the brackets to the Passenger Side. Repeat the following steps on the Driver Side. Ensure fasteners are only hand tight at this point.










Front Bracket


4" Oval Bent End Sidebar 24+ Toyota Tacoma Double Cab




(Fig 4) Attach Passenger/Right Center Mounting Bracket to Center threaded inserts until hand tight











(Fig 7) Attach Passenger/Right Rear Mounting Bracket to Rear threaded inserts until hand tight




Page 3 of 4 5-22-24 (JY)


Follow (Fig 10 – 11) to install the running board. Repeat the following steps on the Driver Side. Ensure fasteners are only hand tight at this point.



3



Level and straighten Sidebar, then tighten all fasteners. At this point, installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.



Page 4 of 4 5-22-24 (JY)