

## Installation Instructions

## PARTS LIST:


Qty	Item Description	Qty	Item Description
1	Driver/left Tube	16	8mm x 22mm OD x 2mm Flat Washers
1	Passenger/right Tube	16	8mm Nylon Lock Nuts
4	Drop Steps	12	8mm Lock Washers
1	Driver/Left Front Mounting Bracket	12	8mm x 30mm Hex Bolts
1	Passenger/Right Front Mounting Bracket	12	8mm x 24mm OD x 2mm Flat Washers
2	Driver/Left Center/rear Mounting Brackets	12	10mm Nylon Lock Nuts
2	Passenger/Right Center/rear Mounting Brackets	12	10mm x 30mm Hex Bolts
8	8mm x 25mm Triangle Double Bolt Plates	24	10mm x 20mm OD x 2mm Flat Washers




Passenger/Right Tube




Driver/Left Tube



Lock Washer



Flat Washer



Lock Nut



Hex Bolt

## TOOLS REQUIRED



Ratchet



13 &amp; 15mm Socket






Extensions









Wrench

1


Follow (Fig 1 – 9) to attach the brackets to the Passenger Side. Repeat the following steps on the Driver Side. Ensure all hardware is hand tightened at this point.






- 2** Follow (Fig 10 – 12) to install the Overland Slider to Passenger Side, then repeat with Driver side. Then attach Drop Steps to each installation location on Overland Slider. Ensure hardware is hand tightened at this point.

(2) 10mm Hex Bolts  
(4) 10mm Flat Washers  
(2) 10mm Nylon Lock Nuts




(Fig 10) Passenger/Right Running Board attached to front Bracket

(1) 8mm Triangle Double Bolt Plate  
(2) 8mm Flat Washers  
(2) 8mm Nylon Lock Nuts



(Fig 12) Attach Drop Steps to Overland Slider



(Fig 11) Passenger/Right Running Board attached to rear Bracket

- 3** Ensure Overland Slider and Drop Step are Level, then tighten all fasteners. Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.



Completed Installation