

2005-2023 Tacoma Differential Drop Kit

Contents:

- (2) 9/16x12 150mm Bolts
- (2) 9/16x12 Lock Nuts
- (2) M8x1.25 35mm Bolts
- (2) 25mm Spacers
- (2) 12mm Spacers

Tools:

- 12, 13, 19, and 22mm sockets/wrenches
- Breaker Bar
- Floor Jack

//Step 1:

Remove the (4) 12mm skid plate bolts [A] and remove skid plate.

//Step 2:

Using a floor jack, support the weight of the differential. Lift it enough to raise it slightly so the front bolts can be removed.

//Step 3:

Remove the (2) bolts holding the differential to the subframe [B] using a 22mm socket for the bottom and a 19mm wrench for the top nut.

//Step 4:

Once bolts are removed, lower the jack slightly to lower differential enough to add the (2) 25mm spacers.

//Step 5:

Install the (2) 25mm spacers in between the differential and subframe [C]. Install (2) 9/16x12 150mm Bolts and lock nuts. Reuse the original bushing washers from the original bolts[D].

//Step 6:

Install skid plate onto vehicle using the (2) original bolts on top. Use included (2) M8x1.25 35mm bolts with 12mm spacers between plate and frame to secure lower skid plate [E].

