



BILLET PEDAL COVER SET

(2024-2025+ TACOMA - WITH AUTOMATIC TRANSMISSION)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Brake Pedal Cover
(1) Throttle Pedal Cover

TOOLS REQUIRED

Heat Gun (Optional)

SKU # TT64564

**STEP 1
(BRAKE)**

Grab the edge of the brake pedal to remove the rubber cover from the brake pedal assembly. Use a heat gun if necessary to give the rubber additional flexibility.

**STEP 2
(BRAKE)**

Fit the brake pedal cover onto the brake pedal assembly, starting with the RH side of the brake pedal. Then, work the rubber lip around the metal brake pedal. Ensure the cover is fully seated around the pedal. Use a heat gun if necessary to give the rubber additional flexibility.



STEP 3 (THROTTLE)

The throttle pedal does not have a rubber cover, the new billet pedal cover will install directly over the vehicle throttle pedal.

Fit the throttle pedal cover onto the throttle pedal assembly, starting with the RH top corner pedal. Then, work the rubber lip around the throttle pedal. Ensure the cover is fully seated around the pedal. Use a heat gun if necessary to give the rubber additional flexibility.

Installation is now complete.