



CUSTOM FIT FLOOR LINERS

(2024+ TACOMA - DOUBLE CAB)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Front Floor Liner
(1) RH Front Floor Liner
(1) Rear Seat Floor Liner

TOOLS REQUIRED

Vacuum Cleaner

STEP 1 [FRONT]



Clean the vehicle floor using a vacuum cleaner.

Locate the vehicle floor anchor points. Turn the anchor point lock 90 degrees to allow new liner installation.

STEP 2 [FRONT]



Fit the new floor liner into the vehicle and onto the mounting anchors. Turn the mounting anchor 90 degrees to lock the liner into place.

Repeat steps 1-2 for the remaining front floor liner.

STEP 3 [REAR]



Clean the vehicle floor using a vacuum cleaner.

STEP 4 [REAR]



Evenly fit the new floor liner onto the vehicle floor.

Installation is now complete.