



BED MAT

(2024-2025+ TACOMA - WITH 5FT BED)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Bed Mat

TOOLS REQUIRED

Non-Abrasive Soap
Hot Water

STEP 1



Clean the inside of the bed using non-abrasive cleaner and water. Allow the bed to dry.

STEP 2



Fit the bed mat into the vehicle. Ensure the rear mounting hooks are above the bed mat surface. Press the mat down in all areas to ensure proper fit. With sun exposure and bed usage over time, the mat will fit flush to the bed floor.

Installation is now complete.

Clean the bed mat with hot water and non-abrasive soap when necessary.