



ARMREST STORAGE BOX

(2024-2025+ TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Storage Tray
(1) Liner

TOOLS REQUIRED

N/A

STEP 1



Clean the center console of items at this time to ensure storage tray fitment is unobstructed.

STEP 2



Fit the tray liner into the storage tray. Fit the rear portion of the storage tray into the vehicle center console, and then place the front portion down to fully seat the tray into place. The storage tray is directional and can only fit one way.

With fitment familiarized, re-install the previously stored center console items by removing the tray, then re-install the tray.

Installation is now complete.