



DASHBOARD STORAGE TRAY FOR 14" SCREEN

(2024+ TACOMA - WITH 14" SCREEN)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Storage Tray
- (2) Silicone Mats
- (1) Alcohol Prep Pad
- (1) Adhesion Promoter Prep Pad

TOOLS REQUIRED

N/A

STEP 1



Clean the vehicle dashboard behind the screen using (1) alcohol prep pad, and allow to fully dry.

Clean the vehicle dashboard behind the screen using (1) adhesion promoter prep pad, and allow to fully dry.

STEP 2



Test fit the tray to the screen before removing the tape backing to familiarize fitment to the dashboard and screen. Once familiar with the fitment, peel the red tape backing from the double sided tape, and fit the storage tray to the screen and dashboard. Firmly press the tray downwards to encourage proper adhesion.

The storage tray has (4) 1/4-20 screw bosses for various universal mounting options (not included). Installation is now complete.