



HIDDEN ARM REST ORGANIZER

(2024-2025+ TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Storage Box
(1) Alcohol Prep Pad
(1) Adhesion Promoter Prep Pad

TOOLS REQUIRED

N/A

STEP 1



Open the center console storage area. Clean the inside walls of the center console lid using (1) alcohol prep pad and allow to fully dry. Once dry, clean the same area using the included (1) adhesion promoter prep pad.

STEP 2



Peel the red tape backing from the double sided tape. With the storage box lid tab facing up, press the storage box into the center console lid. Press along the perimeter to encourage tape adhesion.

Once installed to the console lid, press the door to latch/unlatch the door mechanism.

Installation is now complete.