



# LED LICENSE PLATE LIGHTS

(2016-2023 Tacoma)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(2) LED Lights

### TOOLS REQUIRED

---

Soft Pry Tool

SKU# TT6701

## STEP 1



Using a soft pry tool depress the clip towards the front of the light, pull the light away from the bumper.

## STEP 2



Twist the light socket and remove the factory light. Remove the factory light bulb and install the LED light plug into the socket. Test the lights for functionality prior to re-installing. If the light doesn't illuminate, rotate the LED plug 180\* and try again.

**STEP 3**



Twist the light bulb socket into the LED light housing.

**STEP 4**



Press the light into the bumper. Installation is now complete.