


## 2024+ Tacoma ADJ. Panhard Bar 100ADS-10136

PART NUMBER	DESCRIPTION	QTY
720R82	22+ TUNDRA ALUMINUM PANHARD BAR	1
724R53	22+ TUNDRA PANHARD BAR MISALIGNMENT BUSHING	4
724R60	ROD END, 1"-14, RIGHT HAND THREAD, 7/8" BORE	1
724R64	JAM NUT, 1"-14, RIGHT HAND THREAD, ZINC PLATED, GRADE 5	1
724R61	ROD END, 1"-14, LEFT HAND THREAD, 7/8" BORE	1
724R65	JAM NUT, 1"-14, LEFT HAND THREAD, ZINC PLATED, GRADE 5	1





## 2024+ Tacoma ADJ. Panhard Bar 100ADS-10136

## ADS recommends that all suspension components be installed by a qualified professional. PANHARD BAR ASSEMBLY INSTRUCTIONS:

- 1. Before beginning, secure the vehicle chassis on jack stands, allowing the rear axle to droop. Never work on a vehicle that is not correctly supported.
- 2. Support the rear differential with a hydraulic jack to remove tension on mounting bolts.
- 3. Remove the lower bolt with a 19mm socket. Remove eyelet from axle mount. Retain hardware.
- 4. Remove the upper bolt and nut with a pair of 19mm wrenches. Remove factory panhard bar from vehicle. Retain hardware.
- 5. Pre-assemble billet bar with rod ends and jam nuts making sure there is an equal length of threads showing on both rod ends. Do not tighten at this time. Note: left hand threaded rod end and jam nut will be installed on the Panhard bar side with the round locating mark on bar.
- 6. Using supplied misalignment bushings, loosely install billet panhard bar using factory hardware. Do not torque at this time.
- 7. Remove jacks and lower vehicle to the ground.
- 8. With jam nuts on rod ends loose, turn bar to center axle.
- 9. Raise vehicle securely and support rear axle.
- 10. Remove drivers side of track bar assembly from factory bracket,
- 11. Keeping both rod ends in line, torque Jam nuts to 180 ft-lbs.
- 12. Reinstall drivers side of track bar with factory hardware. Torque to factory spec.
- 13. Verify proper clearance of Panhard Bar from any factory and/or aftermarket components on vehicle.
- 14. Check all fasteners after 50 miles and inspect periodically thereafter.

Toll Free Technical Service: 1-866-464-6553
For online help, please refer to the Technical Information section of our website:

www.holley.com

© 2023 Holley Performance Products, Inc. All rights reserved. Tous Droits Réservés.