



RAIN GUARDS

(2024-2025+ TACOMA - DOUBLE CAB)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Front Rain Guard
(1) RH Front Rain Guard
(1) LH Rear Rain Guard
(1) RH Rear Rain Guard
(4) Alcohol Prep Pads
(4) Adhesion Promoter Prep Pads

TOOLS REQUIRED

N/A

STEP 1 [FRONT]




Clean the designated area of the vehicle using (1) alcohol prep pad, and allow to fully dry.

Once dry, clean the designated area of the vehicle using (1) adhesion promoter prep pad and allow to fully dry.

Test fit the rain guard to the vehicle to familiarize fitment. The guard will fit along the top edge of the door.

STEP 2 [FRONT]



Once familiar with fitment, peel the red tape backing from the rain guard, and firmly press the rain guard to the vehicle to encourage tape adhesion.

Repeat Steps 1-2 for the remaining front rain guard.

Installation is now complete.

STEP 3 [REAR]



Clean the designated area of the vehicle using (1) alcohol prep pad, and allow to fully dry.

Once dry, clean the designated area of the vehicle using (1) adhesion promoter prep pad and allow to fully dry.

Test fit the rain guard to the vehicle to familiarize fitment. The guard will fit along the top edge of the door.

STEP 4 [REAR]



Once familiar with fitment, peel the red tape backing from the rain guard, and firmly press the rain guard to the vehicle to encourage tape adhesion.

Repeat Steps 3-4 for the remaining rear rain guard.

Installation is now complete.