



MIRROR MOUNTED SMOKED LED SEQUENTIAL TURN SIGNALS

(2016-2023 TACOMA)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Turn Signal
(1) RH Turn Signal

TOOLS REQUIRED

Phillips Head Screw Driver

SKU: TT6983

STEP 1



Carefully pull the mirror cover from the mirror. The cover is clipped onto the mirror. Firmly pull from the top edge and work around the mirror until it comes off.

STEP 2



Remove the (2) Phillips head screws and carefully pull back the plastic bracket. Pull the factory turn signal from the mirror housing.



STEP 3

Unplug the turn signal from the vehicle.



STEP 4

Reinstall the smoked turn signal in reverse order.