



Thank you for your business

- 1. Remove inner rail for sliding latch if installed. On the bed frame on the truck.**
- 2. Attach the stand offs to the bottom of the PSD rack using supplied Stainless Steel bolts**
- 3. If you had the sliding latch rail on the truck, place the top of the PSD under the rail and tighten down.**
- 4. If you did not have the rail on the truck, locate the upper holes on the bed rail and use supplied stainless steel bolts and washers to attach the PSD rack to the bed rail.**

If you have any questions contact us. sales@orangeboxxfab.com

Our hours are Monday - Friday 9am - 4:30 pm eastern

Call us (336)804-0571

Tag us on Instagram

#orangeboxxfab