## 5INCH OVAL STRAIGHT SIDEBAR 2022-2023 TOYOTA TUNDRA CREWMAX

## PARTS LIST:

1 Dr	iver/Left Sidebar		3	Passenger/Right Rear Mounting Brackets
1 Pa	assenger/Right Sideba	r	16	8mm x 30mm Hex Bolts
1 Dr	river/Left Front Mountin	ng Bracket	16	8mm x 25mm Combo Bolts
1 Pa	assenger/Right Front N	Nounting Bracket	16	8mm Lock Washers
3 Dr	river/Left Rear Mountin	ng Brackets	16	8mm x 24mm OD x 2mm Flat Washers
(3) Passenger/ Right Rear Mounting Brackets Mounting Brackets				
Passenger/Right Passenger/Right Front Driver/Left Front Front				
510		Mounting Bracket		unting Bracket

## PROCEDURE:

- 1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY. ASSISTANCE IS HIGHLY RECOMMENDED.
- 2. Starting on the Passenger/Right side of the vehicle and remove the plastic plugs or hex bolts from the factory mounting location along the bottom of the body, (Figures 1 & 4).
- 3. Select the Passenger/Right Front Mounting Bracket. Attach the Bracket to the front location with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, (Figures 2 & 3). Do not tighten hardware.
- 4. Repeat Steps 2 & 3 to attach the (3) Rear Mounting Brackets, (Figures 4-8).
- 5. Unwrap the Passenger/Right Sidebar. Place the Sidebar on top of the (4) Mounting Brackets. IMPORTANT: Do not slide the Sidebar on the Brackets, (front to back or rotate), or damage to the finish may result. Attach the Sidebar to the Brackets with (8) 8mm Flat Washers and (8) 8mm Nylon Lock Nuts, (Figure 9). Do not tighten hardware.
- 6. Level and adjust the Sidebar and tighten all hardware.
- 7. Repeat **Steps 1—8** to attach the Driver/Left Sidebar.
- 8. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

**To protect your investment**, Do not use any type of polish or wax that may contain abrasives that could damage the finish. Use only mild soap to clean the Sidebars.





## 5INCH OVAL STRAIGHT SIDEBAR 2022-2023 TOYOTA TUNDRA CREWMAX Passenger/Right Side Installation Pictured

