



OE STYLE POWERED HEATED MIRRORS WITH LED AMBER TURN SIGNALS

(2007-2017 TUNDRA)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Mirror Assembly
(1) RH Mirror Assembly

TOOLS REQUIRED

Small Pry Tool
10mm Deep Socket
Ratchet

SKU # TU47338

STEP 1

Open the vehicle door. Locate and remove the trim panel behind the mirror assembly.

STEP 2

Along the inside of the door panel under the mirror, locate the plastic retaining clip. Press the center of the clip slightly, and then remove the clip from the door panel.



STEP 3

Pull back on the top of the door panel, and unplug the mirror assembly. Then, while supporting the mirror, remove (3) 10mm nuts from the mirror assembly using a 10mm deep socket and a ratchet.



STEP 4

Fit the new mirror to the vehicle, ensuring the electrical connector and mirror gasket fits properly to the door. Secure the mirror into place using the (3) 10mm nuts, tighten evenly until secure.

Plug the mirror assembly into the vehicle door harness. Re-install the door panels to the vehicle reusing the original hardware.

Installation is now complete.