



MUD GUARDS

(2022-2025+ TUNDRA)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Front Mud Guard
(1) RH Front Mud Guard
(1) LH Rear Mud Guard
(1) RH Rear Mud Guard
(8) Phillips Screws
(4) V-Clips

TOOLS REQUIRED

10mm Socket
1/4" Drive Ratchet
Phillips Screwdriver

STEP 1 [FRONT]



Remove the (4) 10mm screws from the inner fender liner.

Note: For easier access, turn the steering wheel to move the front wheel away from the fender.

STEP 2 [FRONT]



Fit the appropriate mud guard to the vehicle, and secure into place using the original (4) 10mm screws.

Note: Do not over-tighten the mud guard into place. The OEM fender liner fastener mount is plastic and can strip if over-tightened.

Repeat Steps 1-2 for the remaining front mud guard.

STEP 3 [REAR]



Remove the (3) 10mm screws from the inner fender liner. Locate the (2) screw mounts in the inner fender liner.

Note: Removing the rear wheel may be necessary for adequate working room.

STEP 4



Fit the appropriate mud guard to the vehicle, and secure into place using the original (3) 10mm screws. Then, secure the mud guard to the inner fender liner mounts using (2) Phillips screws. If necessary, use the included V-Clips if the inner fender liner does not have screw mounts.

Note: Do not over-tighten the mud guard into place. The OEM fender liner fastener mount is plastic and can strip if over-tightened.

Repeat Steps 3-4 for the remaining rear mud guard.

STEP 5



Installation is now complete.