



---

# FLOOR LINERS

(2014-2021 TUNDRA - DOUBLE CAB & CREWMAX)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner
- (1) Rear Floor Liner

### TOOLS REQUIRED

---

Vacuum Cleaner

SKU # TU56987



---

**STEP 1**  
**[FRONT]**



Locate the vehicle floor anchor points. Turn the anchor point lock 90 degrees to allow new liner installation. Remove any existing floor mat/liner from the vehicle.

Clean the vehicle floor using a vacuum cleaner.

---

**STEP 2**  
**[FRONT]**



Fit the new floor liner into the vehicle and onto the mounting anchors. Turn the mounting anchor 90 degrees to lock the liner into place.

Repeat Steps 1-2 for the remaining front floor liner.



**STEP 3**  
**[REAR]**



Clean the vehicle floor using a vacuum cleaner.

**STEP 4**  
**[REAR]**



Evenly fit the new floor liner onto the vehicle floor. Ensure the foot vents under the front seats are not blocked by the liner, adjust as necessary to allow clearance.

Installation is now complete.