



RAIN GUARDS - OUT CHANNEL

(2007-2021 TUNDRA - DOUBLE / CREW MAX CAB)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Rain Guard
- (1) RH Front Rain Guard
- (1) LH Rear Rain Guard
- (1) RH Rear Rain Guard
- (4) Alcohol Prep Pads
- (4) Adhesion Promoter Prep Pads

TOOLS REQUIRED

N/A


STEP 1



- Clean the top of the vehicle door using (1) alcohol prep pad, and allow to dry.
- Clean the top of the vehicle door using (1) adhesion promoter prep pad, and allow to dry.

Test fit the rain guard to the vehicle door before removing the tape backing to familiarize fitment.

STEP 2



Once familiar with fitment, peel the red tape backing from the rain guard, and firmly press the guard to the vehicle door.

Repeat Steps 1-2 for all remaining rain guards.