



LED FRONT CORNER LIGHTS

(1997-2001 CHEROKEE XJ)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Corner Lamp
- (1) RH Corner Lamp

TOOLS REQUIRED

Phillips Screwdriver

1. Locate the (2) Phillips screws above the headlight assembly. Remove the (2) screws.
2. Pull the headlight and turn signal surround bezel away from the vehicle, and set aside.
3. Locate and remove (2) Phillips screws securing the corner light from the vehicle under the headlight assembly.
4. Twist and remove the light sockets from the light housing, and remove the bulbs.
5. Identify the LH and RH side of the provided corner lamps. Once identified, plug in the light bulb connector on each light into the appropriate vehicle light socket. Test the lighting.
Note: The light socket connections may be polarized. If the lighting does not initially work, turn each light bulb connector 180° in the vehicle socket, and re-test the lighting.
6. With all lighting working, fit the light sockets into the new light housings, and install the light to the vehicle using the original (2) Phillips screws.
7. Re-install the trim panel to the vehicle using the original (2) Phillips screws.
8. Repeat Steps 1-7 for the opposite side corner light installation.
Installation is now complete.