

LED SIDE MARKER LAMPS

(1997-2001 CHEROKEE XJ)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Side Marker Lamp
(1) RH Side Marker Lamp

TOOLS REQUIRED

Phillips Screwdriver

1. Locate and remove (2) Phillips screws securing the corner marker light to the vehicle fender.
2. Twist and remove the light socket from the light housing, and remove the bulb.
3. Identify the LH and RH side of the provided side marker lamps. Once identified, plug in the light bulb connector and test the lighting.
Note: The light socket connection may be polarized. If the lighting does not initially work, turn the light bulb connector 180° in the vehicle socket, and re-test the lighting.
4. With the light working, fit the light socket into the new light housing and install the light to the vehicle using the original (2) Phillips screws.
5. Repeat Steps 1-4 for the opposite side corner marker light installation. Installation is now complete.