



LED HALO TAIL LIGHTS

(2007-2018 WRANGLER JK)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Tail Light
(1) RH Tail Light

TOOLS REQUIRED

Phillips Head Screw Driver

SKU: J138358

STEP 1



Using a Phillips head screwdriver remove the inner most screws securing the tail light the vehicle.

STEP 2



Depress the tab on the electrical connector while pulling the electrical connectors apart. Remove and store the lights in a safe place.

STEP 3



Identify the top of the light by looking at the light trim. Note: Wider section of the trim faces up. In the above photo, this is the Left Hand (LH) tail light.

STEP 4



Plug the new tail light into the factory wiring. Ensure the plugs clip together. Failure to do so can cause the lights to not function correctly. Reinstall the tail light using the factory screws. Repeat the process for both tail lights to complete the installation.