



# ALUMINUM FUEL FILLER DOOR COVER

(2018-2023+ WRANGLER JL - EXCLUDING DIESEL MODEL)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Fuel Door Assembly

### TOOLS REQUIRED

---

10mm Socket  
Ratchet  
Flathead Screwdriver  
Plastic Pry Tool

SKU # J153595-JL



## STEP 1

Remove the small plastic cover on the LH side cargo area panel, and remove the (1) 10mm tail light bolt. Once removed, pull to tail light to remove the assembly from the body, unplug the harness and set aside.



## STEP 2

Through the tail light hole, use a long pry tool/flathead screwdriver to dislodge the mounting clips retaining the trim to the vehicle body. Remove the fuel cap, then remove the trim bezel.

Note: The lower retainers are the most accessible, once the lower retainers are dislodged, the trim can be manipulated to dislodge the uppers during removal.



## STEP 3

Press the new fuel door to the vehicle, ensuring all retainers are firmly clipped to the vehicle body. Re-install the fuel cap and attach the tether to the fuel door housing.



## STEP 4

Re-install the tail light to the vehicle reusing the original (1) 10mm bolt.

Installation is now complete.