

## 4-LAYER BREATHABLE FULL CAR COVER

(WRANGLER)

INSTALLATION INSTRUCTIONS

**CONTENTS** 

(1) All Weather Cover

**TOOLS REQUIRED** 

Adjustable Wrench Exterior Cleaner (Optional)



STEP 1



Clean vehicle. Remove vehicle antenna using an adjustable wrench.



STEP 2

Lay the cover out to find the (2) straps. Unclip (2) buckles on the straps located under the cover. Locate front of cover - look for sticker that points front.

The arrow will point forward away from vehicle when cover is installed.





STEP 3

Drape cover over vehicle. Pull all the way over vehicle.



STEP 4

Once fully fitted, using the (2) straps, buckle the straps together on each side.

Installation is now complete.